





# West Hall

- Introductory Remarks**
- : A Zone
  - ▨ : B Zone
  - ▩ : The range where the setting of B zone is permitted. (The applicable booth is "W07".) It is permitted to set up the B zone covering 237m<sup>2</sup> either in a "L" letter-form or in the south side of the booth. (The total area of the B zone, however, should be 2/3 of the whole booth.)
  - ▧ : The designated range to connect in-stand passageways. (Passageways should be straight if possible and not less than 6.0m in width within the designated 10m range.)
  - ▯ : Overhead Banners
    - A type : Area of stand 2000m<sup>2</sup> and over ×2 (W 4500 X H 6500)
    - B type : Area of stand Less than 600m<sup>2</sup> ×1 (W 4000 X H 6000)
  - ▭ : Parts Section Overhead Banners (W 4500 X H 6000)

Location of banners is subject to change due to the structure of hall ceilings.



- ⊙ : Built-in Hydrant
- ⊕ : Built-in hose
- ⊖ : Hydrant



TITLE			West Hall (1·2·3Hall) (Passenger Cars/Parts) Regulations on Stand Layout Design		
SCALE		A1:1/300	A3:1/600	DATE	03.03.05.
DESIGN		design office SOUP		DRAFT	
NO.			THE 37th TOKYO MOTOR SHOW		

03.09.01.